

PEM-X1 WÂGNER

OPERATING MANUAL

# **Table of Contents**

<b>1</b> 1.1 1.2 1.3 1.4	<b>ABOUT THIS MANUAL</b> Preface Warnings, Notices, and Symbols in this Operating Manual Languages Abbreviations	<b>6</b> 6 7 7
2	CORRECT USE	<b>8</b>
2.1	Device Type	8
2.2	Type of Use	8
2.3	Use in Potentially Explosive Areas	9
2.4	Safety Parameters	9
2.5	Processible Working Materials	9
2.6	Reasonably Foreseeable Misuse	10
2.7	Residual Risks	10
<b>3</b>	<b>IDENTIFICATION</b>	<b>11</b>
3.1	Explosion Protection Identification	11
3.2	Permissible Device Combinations	11
<b>4</b> 4.1 4.1.2 4.1.3 4.2 4.2.1 4.2.2 4.2.3 4.2.4 4.2.5 4.3 4.4	GENERAL SAFETY INSTRUCTIONS Safety Instructions for the Operator Electrical Devices and Equipment Staff Qualifications Safe Work Environment Safety Instructions for Staff Safe Handling of WAGNER Powder Spray Devices Grounding the Device Product Hoses Cleaning Handling Powder Lacquers Information About Safe Discharges Protective and Monitoring Equipment	<b>12</b> 12 12 12 13 13 13 13 13 14 14 15 16
<b>5</b>	DESCRIPTION	<b>17</b>
5.1	Spray Gun Design	17
5.2	Functioning of the Spray Gun	17
5.3	Technical Data	18
5.3.1	Dimensions	19
5.4	Permitted Accessories	20
5.5	Scope of Delivery	20
<b>6</b> 6.1 6.2 6.3 6.4 6.4.1 6.5 6.6 6.6.1	ASSEMBLY AND COMMISSIONING Training Assembly/Commissioning Staff Storage Conditions Installation Conditions Preparing the Spray Gun Selection of the Suitable Nozzle System Connecting the Spray Gun Grounding Grounding	<b>21</b> 21 21 22 22 24 26 27

PEM-X1

OPERATING MANUAL

# **Table of Contents**

7	OPERATION	28
7.1	Training the Operating Staff	28
7.2	Safety Instructions	28
7.3	Optimizing the Powder Cloud for Your Coating	29
7.3.1	Recommended Settings for Total Air Volume	29
7.4	Switching Off the Spray Gun	30
7.5	Adjustment of Powder Quantity	31
7.6	"Double Click" Program (High Dynamic Remote)	32
7.7	Reproducible Setting of the Nozzle Position	33
8	CLEANING AND MAINTENANCE	34
8.1	Cleaning	34
8.1.1	Cleaning Staff	34
8.1.2	Safety Instructions	34
8.1.3	Cleaning Procedures	35
8.2	Maintenance	36
8.2.1	Maintenance Staff	36
8.2.2	Safety Instructions	36
8.2.3	Maintenance Procedures	37
8.2.4	Replacing the Spray Gun	38
8.3	Removing the Fan spray nozzle	39
8.4	Fitting the Fan spray nozzle	40
8.5	Removing the Round spray nozzle	41
8.6	Fitting the Round spray nozzle	42
8.7	Replacing the Protective Wedge	43
8.8	Changing from Fan spray nozzle to Round spray nozzle	45
8.9	Assembly of the CoronaStar	47
8.10	Replacing the Suspension Hook	48
9	INSPECTIONS IN ACCORDANCE WITH DIN EN 50050-2: 2014	49
9.1	Overview of Inspections	50
10	DISASSEMBLY AND DISPOSAL	51
10.1	Disassembly	51
10.2	Disposal	51
11	TROUBLESHOOTING AND RECTIFICATION	52
12	ACCESSORIES	54
12.1	Fan spray nozzle	54
12.2	Deflector Cone	54
12.3	Electrode Holder	54
12.4	Hose Take-up	55
12.5	CoronaStar Retrofit Set	55
12.6	Wedge Tool	55
12.7	Nozzle Extension, X1 VL 150/300/500	56
12.8	Nozzle Extension, X1 VL 750	56
12.9	Powder Hose	57
12.10	Gun Connection Cable	57
12.11	Wall Mount	57
12.12	Recipe Sticker	58
12.13	Powder Measuring Adapter	59

PEM-X1

## OPERATING MANUAL

# **Table of Contents**

13	SPARE PARTS	60
13.1	How Can Spare Parts Be Ordered?	60
13.2	PEM-X1 Corona Manual Gun With a Fan spray nozzle	61
13.3	PEM-X1 Corona Manual Gun With a Round spray nozzle	62
13.4	Electrode Holder, X1 R	63
14	DECLARATION OF WARRANTY AND CONFORMITY	64
14.1	Important Notes Regarding Product Liability	64
14.2	Warranty Claim	64
14.3	Declaration of Conformity	65
14.4	EC Type Examination Certificate	66
14.5	FM Approval	67

PEM-X1

**OPERATING MANUAL** 

## **1** ABOUT THIS MANUAL

#### **1.1** PREFACE

The operating manual contains information about safely operating, maintaining, cleaning and repairing the device.

The operating manual is part of the device and must be available to operating and service staff.

Operating and service staff should be instructed according to the safety instructions. The device may only be operated in compliance with this operating manual.

This equipment can be dangerous if it is not operated according to the instructions in this operating manual.

Electrostatic manual coating systems may only be operated by qualified personnel.

#### 1.2 WARNINGS, NOTICES, AND SYMBOLS IN THIS OPERATING MANUAL

Warning instructions in this operating manual highlight particular dangers to users and to the device and state measures for avoiding the hazard. These warning instructions fall into the following categories:

**Danger** - immediate risk of danger. Non-observance will result in death or serious injury.

Non-observance may result in death or serious injury.

Caution - a possibly hazardous situation. Non-

Warning - possible imminent danger.

observance may result in minor injury.

Notice - a possibly hazardous situation.

Non-observance may result in damage to property.



#### A DANGER

This notice warns you of a hazard! Possible consequences of not observing the warning instructions. The signal word indicates the hazard level.

 $\rightarrow$  The measures for preventing the danger and its consequences.



#### WARNING

This notice warns you of a hazard! Possible consequences of not observing the warning instructions. The signal word indicates the hazard level.

The measures for preventing the danger and its consequences.



This notice warns you of a hazard! Possible consequences of not observing the warning instructions. The signal word indicates the hazard level.

→ The measures for preventing the danger and its consequences.

NOTICE

This notice warns you of a hazard! Possible consequences of not observing the warning instructions. The signal word indicates the hazard level.

 $\rightarrow$  The measures for preventing the danger and its consequences.

Note - provides information about particular characteristics and how to proceed.



OPERATING MANUAL

## **1.3** LANGUAGES

The operating manual is available in the following languages:

German	2326019	English	2326020
French	2326021	Italian	2326022
Spanish	2326023	Russian	2333344
Chinese	2333345	Dutch	2337552
Swedish	2345951	Hungarian	2341080
Portuguese	2345347	Danish	2348202
Finnish	2348203	Norwegian	2348238

## **1.4** ABBREVIATIONS

Stk	Number of pieces
Pos	Position
К	Marking in the spare parts lists
Order No.	Order number
ET	Spare part

VERSION 03/2014

ORDER NUMBER DOC 2326020

PEM-X1

**OPERATING MANUAL** 

## **2** CORRECT USE

## 2.1 DEVICE TYPE

Powder spray guns for manual coating of grounded work pieces

## 2.2 TYPE OF USE

The PEM-X1 manual powder spray gun is designed for the electrostatic coating of work pieces with organic powders. Any other form of use is considered non-intended use. Wagner disclaims liability for any damage resulting from non-intended use. Electrostatic manual coating systems may only be used in spray areas equipped in accordance with EN 12981 or under equivalent ventilation conditions.

## **2.3** USE IN POTENTIALLY EXPLOSIVE AREAS

In explosion hazard areas, only use approved explosion-proof electrical devices. This type A-P electrostatic powder spray gun is suitable for processing industrial powder paints for coating electrically conductive objects and can be used in potentially explosive areas (zone 22). (See Chapter 3.1 Explosion Protection Identification).





#### **OPERATING MANUAL**

#### **2.4** SAFETY PARAMETERS

WAGNER accepts no liability for any damage arising from non-intended use.

- → Electrostatic manual coating systems may only be operated in an undamaged condition. Damaged devices must be decommissioned immediately and repaired immediately.
- $\rightarrow$  Use the device only to work with the products recommended by WAGNER.
- $\rightarrow$  Operate only the device as a whole.
- → Do not deactivate safety fixtures.
- → Spare parts and accessories may have safety-relevant properties. Use only WAGNER original spare parts and accessories.

The manual powder spray gun may only be operated under the following conditions if:

- → the operating staff have previously been trained on the basis of this operating manual,
- $\rightarrow$  the safety regulations listed in this operating manual are observed,
- ightarrow the operating, maintenance and repair information in this operating manual is observed,
- → and the statutory requirements and accident prevention regulations standards in the country of use are observed.

#### **2.5** PROCESSIBLE WORKING MATERIALS

- Types of powder which can be charged electrostatically
- Metallic powder



OPERATING MANUAL

#### **2.6** REASONABLY FORESEEABLE MISUSE

The following is prohibited:

- coating work pieces which are not grounded,
- unauthorized conversions and modifications to the spray gun,
- processing liquid or similar coating products,
- using defective components, spare parts, or accessories other than those described in Chapter 12 of this operating manual.

The forms of misuse listed below may result in physical injury or property damage:

- Use of damp powder lacquer
- Incorrectly set values for powder discharge
- Incorrectly set electrostatic values
- Use of defective components and accessories
- Use for foodstuffs
- Use in the pharmaceutical sector
- Use with non-authorized control units

## 2.7 RESIDUAL RISKS

Residual risks are risks which cannot be excluded even in the event of correct use. If necessary, warning and prohibition signs at the relevant points of risk indicate residual risks.

Residual risk	Source	Consequences	Specific measures	Lifecycle phase
Skin contact with	Handling powder	Skin irritation,	Wear protective	Operation,
powder lacquers	lacquers and	allergies	clothing,	
and cleaning agents	cleaning agents		observe safety data	maintenance,
			sheets	disassembly
Powder lacquer	Lacquering outside	Inhalation of	Observe working	Operation,
in air outside the	the defined working	substances	and operating	maintenance
defined working	area	hazardous to health	instructions	
area				

OPERATING MANUAL

## **3** IDENTIFICATION

### **3.1** EXPLOSION PROTECTION IDENTIFICATION

Gun type:	PEM-X1		
Manufacturer:	J. Wagner AG		
	CH - 9450 Altstätten		
<b>( €</b> <sub>0102</sub> <b>€</b>	II 2 D 2mJ 85 ℃		
CE:	European Communities		
0102:	Number of notified body which issues the recognition of quality assurance in production		
Ex:	Symbol for explosion protection		
II:	Device class II		
2:	Category 2		
D:	Ex-atmosphere dust		
2mJ:	Maximum ignition energy 2 mJ		
85 °C:	Maximum surface temperature		

The EC type examination certificate PTB 12 ATEX 5002 can be found in Chapter 14.4.

## **3.2** PERMISSIBLE DEVICE COMBINATIONS



The PEM-X1 powder spray gun may only be connected to the control devices listed below:

- EPG-Sprint X with the corresponding PI-F1/HiCoat ED-F powder injector
- EPG-Sprint with the corresponding PI-F1/HiCoat ED-F powder injector\*
- EPG S2 with the corresponding PI-F1/HiCoat ED-F powder injector\*
- \* The remote control function of the PEM-X1 spray gun is not available when using these control units.

Permissible device combinations for the USA and Canada, see Chapter 14.5 "FM Approval".

**PEM-X** 



**OPERATING MANUAL** 

## **4** GENERAL SAFETY INSTRUCTIONS

#### 4.1 SAFETY INSTRUCTIONS FOR THE OPERATOR

- $\rightarrow$  Keep this operating manual at hand near the device at all times.
- → Always follow local regulations concerning occupational safety and accident prevention.

#### 4.1.1 ELECTRICAL DEVICES AND EQUIPMENT

- → To be provided in accordance with the local safety requirements with regard to the operating mode and ambient influences.
- → May only be maintained by skilled electricians.
- → Must be operated in accordance with the safety regulations and electrotechnical regulations.
- → Must be repaired immediately in the event of problems.
- → Must be decommissioned if they pose a hazard.
- → Must be de-energized before work is commenced on active parts.
- → Secure the device against being switched back on without authorization. Inform staff about planned work.
- → Observe electrical safety regulations.

## 4.1.2 STAFF QUALIFICATIONS

 $\rightarrow$  Ensure that the device is operated, maintained and repaired only by trained persons.

#### 4.1.3 SAFE WORK ENVIRONMENT

- → The floor in the working area must be electrostatically conductive (measurements according to EN 1081 and EN 61340-4-1).
- → The footwear worn by the operators must comply with the requirements of ENISO 20344. The measured insulation resistance must not exceed 100 M $\Omega$  (megaohms).
- → The protective clothing, including gloves, must comply with the requirements of EN ISO 1149-5. The measured insulation resistance must not exceed 100 M $\Omega$  (megaohms).
- → The powder release must be electrically interlocked with the powder spray system's exhaust air equipment.
- → Excess coating product (overspray) must be collected up safely.
- → Ensure that there are no ignition sources such as naked flames, sparks, glowing wires, or hot surfaces in the vicinity. Do not smoke.
- → Maintain sufficient quantities of suitable fire extinguishers and ensure that they are serviceable.
- → The operating company must ensure that an average concentration of powder lacquer in the air does not exceed 50% of the lower explosion limit (LEL = max. permitted concentration of powder to air). If no reliable LEL value is available, the average concentration must not exceed 10 g/m<sup>3</sup>.





**OPERATING MANUAL** 

#### 4.2 SAFETY INSTRUCTIONS FOR STAFF

- → Always follow the information in this manual, particularly the general safety instructions and the warning instructions.
- → Always follow local regulations concerning occupational safety and accident prevention.
- → Under no circumstances may people with pacemakers enter the area where the high-voltage field between the spray gun and the work piece to be coated builds up!

#### 4.2.1 SAFE HANDLING OF WAGNER POWDER SPRAY DEVICES

- $\rightarrow$  Do not point spray guns at people.
- → Before all work on the device, in the event of work interruptions and functional faults:
  - Switch off the energy/compressed air supply.
  - Secure the spray gun against actuation.
  - Relieve pressure on spray gun and device.
  - In case of functional faults: Identify and correct the problem, proceed as described in the "Fault Rectification" chapter.

## 4.2.2 GROUNDING THE DEVICE

The electrostatic charge may, in certain cases, give rise to electrostatic charges on the device. This may result in the formation of sparks or flames when discharging.

- → Ensure that the device is grounded before each coating process.
- → All the system's conductive elements, such as floors, walls, ceilings, protective grating, transport equipment, work pieces, powder tanks, automatic moving devices or construction parts etc. in the spray area, with the exception of parts which carry high-voltage during operation, must be connected to the grounding system. Parts of the booth must be grounded in accordance with EN 12981.
- → Ensure that all persons inside the working area are grounded, e.g., by wearing electrostatically conductive shoes.
- $\rightarrow$  The functionality of grounding cables must be checked regularly (see EN 60204).

## 4.2.3 PRODUCT HOSES

→ Only use an original Wagner powder hose.





P	ΕN	N۰	-X	1
	F	N	E	R

#### **OPERATING MANUAL**



#### 4.2.4 CLEANING

- → Before starting cleaning or any other manual work, the high-voltage in the spray area must be shut down and locked to prevent it from being switched back on.
- $\rightarrow$  Lock the compressed air supply and decompress the device.
- $\rightarrow$  Secure the device against being switched back on without authorization.
- $\rightarrow$  Use only electrically conducting and grounded tanks for cleaning fluids.
- $\rightarrow$  Preference should be given to non-flammable cleaning fluids.
- → Flammable cleaning liquids may only be used if, after switching off the high-voltage, all high-voltage conducting parts are discharged to a discharge energy of less than 0.24 mJ before they can be accessed.
- Most flammable solvents have an ignition energy of around 0.24 mJ or 60 nC.
- $\rightarrow$  The cleaning agent's flash point must be at least 15 K above the ambient temperature.
- → Only mobile industrial vacuum cleaners of design 1 (see EN 60335-2) may be used to remove dust deposits.

#### 4.2.5 HANDLING POWDER LACQUERS

- → When preparing or processing the powder and cleaning the device, take note of the processing regulations, laid down by the manufacturer of the powder lacquers, being used.
- → Take note of the manufacturer's instructions and the relevant environmental protection regulations when disposing of powder lacquers.
- → Take the prescribed safety measures, in particular the wearing of safety glasses and safety clothing as well as the use of protective hand cream.
- $\rightarrow$  Use a mask or breathing apparatus if necessary.
- → To ensure sufficient protection of health and the environment, only operate the device in a powder booth or on a spray wall with activated ventilation (exhaust air).





#### 4.3 INFORMATION ABOUT SAFE DISCHARGES



With the high-voltage switched on, a luminous or corona discharge occurs at the electrode tip; this can only be seen in the dark. This physical effect can be seen when the electrode is brought near the grounded work piece. This luminous discharge does not involve any ignition energy and has no effect on system handling. When the electrode approaches the work piece, the control unit automatically reduces the high-voltage to a safe value. If you touch plastic parts of the spray gun with your finger, harmless discharges may occur due to the high-voltage field around the spray gun (so-called brush discharges). However, these do not contain any ignition energy.

PEM-X1

#### OPERATING MANUAL

## 4.4 PROTECTIVE AND MONITORING EQUIPMENT

Incorrect use!           Risk of injury and damage to the device.		
<ul> <li>→ Protective and monitoring equipment must not be removed, modified or rendered unusable.</li> <li>→ Regularly check for perfect functioning.</li> <li>→ If defects are detected on protective and monitoring equipment, the system must not be operated until these defects are remedied.</li> </ul>		

To prevent electrostatic flashover, the union nut for securing the nozzles is designed in a certain geometric shape.

This shape, together with the shape of the fan spray nozzle or deflector cone sleeve, prevents the nozzles from coming loose unintentionally (see Chapters 8.3, 8.5, 8.8). To ensure safety, only use genuine Wagner spare parts!



## **5 DESCRIPTION**

## 5.1 SPRAY GUN DESIGN



	Designation
Α	Suspension hook
В	Handle
С	Electrical connection cable
D	Powder hose connection
E	Trigger lever
F	Union nut
G	Round spray nozzle
Н	Atomizing air connection
I	Fan spray nozzle
K	Buttons to adjust the powder quantity
L	Spray gun body

## 5.2 FUNCTIONING OF THE SPRAY GUN

High-voltage is activated in the manual gun when the trigger is actuated! The powder supply and air supply to the gun are activated at the same time. The control unit must be switched off in order to lock the spray gun. To prevent electrostatic flashover, the union nut for securing the nozzles is designed with a labyrinth.

PEM-X1

OPERATING MANUAL

## **5.3** TECHNICAL DATA

Dimensions:	
Length/width/height	see Chapter 5.3.1
Weight	490 g; 1.08 lbs
Electrical:	
Input voltage	maximum 22 Vpp
Input current	maximum 0.9 A
Frequency	19 - 30 kHz
Output voltage	maximum 100 kV DC
Maximum Corona current	120 μA
Polarity	negative
Construction type in accordance with EN 50050-2	
Protection class	IP 64
Pneumatic:	
Input air pressure (atomizing air volume)	maximum 3 bar; 0.3 MPa, 43.51 psi
Powder output quantity	maximum 450 g/min;
	maximum 0.99 lbs/min
Ambient conditions:	
Operating temperature range	5 - 45 °C; 41 - 113 °F
Relative humidity	< 75 %



#### **Ambient conditions:**

If low-melting powders are used, the ambient temperature may have to be lower than 30 °C; 86 °F.

#### Volume measures:

for volumes specified in Nm<sup>3</sup> (standard cubic meters). One cubic meter of a gas at 0 °C and 1.013 bar is called norm cubic meter.

PEM-X1

## OPERATING MANUAL

## 5.3.1 DIMENSIONS



Measurement	mm	inch
A*	335/349	13.19/13.74
В	248	9.76
C	45	1.77

\* with fan spray nozzle/with deflector cone



#### OPERATING MANUAL

#### **5.4** PERMITTED ACCESSORIES

Only the accessories listed in the "Accessories" chapter of this operating manual may be connected to the PEM-X1 powder spray gun.

The accessories listed in the "Accessories" chapter were included in the EC type examination and are approved for use with the gun.

#### 5.5 SCOPE OF DELIVERY

Stk	Order No.	Designation	
1	2322587	PEM-X1 manual gun with a fan spray nozzle	
	2335844	PEM-X1 manual gun with a round spray nozzle	
1		Nozzle set	
The standard equipment includes:			
1	2326024	Declaration of conformity	
1	2326019	Operating manual, German	
1	see Chapter 1.3	Operating manual in local language	

**OPERATING MANUAL** 

## **6** ASSEMBLY AND COMMISSIONING

#### **6.1** TRAINING ASSEMBLY/COMMISSIONING STAFF



#### **6.2** STORAGE CONDITIONS

Until the point of assembly, the powder spray gun must be stored in a dry location, free from vibrations and with a minimum of dust. The powder spray gun must be stored in closed rooms.

The air temperature at the storage location must be between 5 - 45 °C; 41 - 113 °F. The relative air humidity at the storage location must not exceed 75%.

#### **6.3** INSTALLATION CONDITIONS

The air temperature at the assembly site must be between 5 - 45 °C; 41 - 113 °F. Depending on the powder lacquer used, the maximum permissible ambient temperature for reliable operation can be significantly below +40 °C; 104 °F. The relative air humidity at the assembly location must not exceed 75%.

PEM-X1

OPERATING MANUAL

## **6.4** PREPARING THE SPRAY GUN

## **6.4.1** SELECTION OF THE SUITABLE NOZZLE SYSTEM

The process of changing from the fan spray nozzle to the deflector cone is described in Chapter 8.8 "Changing from Fan spray nozzle to Round spray nozzle". You will find the article numbers of the different nozzles in Chapter 12 "Accessories".

Nozzle	Application overview	Powder cloud
Fan spray nozzle	Complex part geometries	Widely spread flat powder cloud
P_01664	<ul> <li>Flat work pieces (reduced picture frame)</li> <li>Profiles</li> <li>Undercuts</li> </ul>	
Deflector cone		Round powder cloud:
P_01665	<ul><li>Wire goods</li><li>Grid designs</li><li>Small components</li></ul>	Size of the powder cloud is dependent on the deflector plate diameter

Nozzle	Application	Distance to work piece (mm)	Powder output (g/min)
P_01664	<ul> <li>Universal</li> <li>Deep and complex part geometries</li> <li>Extensive work pieces</li> </ul>	120 300	50 300

The spray width can be adjusted by the sliding ring.

	Rear sliding ring Wide cloud Cloud opening angle approx. 80°
	Front sliding ring, front Narrow cloud Cloud opening angle approx. 60°
P_02209	Front sliding ring, front, turned by 90° Extra narrow cloud Cloud opening angle approx. 40°



#### OPERATING MANUAL

Deflector cone	Application	Distance to work piece (mm)
R18	Ø 18 mm ● Smaller flat parts	100 300
R25	Ø 25 mm ● Medium sized flat parts	100 300
R34	Ø 34 mm • Large flat parts	100 300

Output quantity [g/min]			
	Overall air		
Feed air [%]	4.00 Nm <sup>3</sup> /h	5.00 Nm³/h	6.00 Nm³/h
50	140	170	210
60	200	240	260
70	250	270	300
80	300	320	350
90	330	360	380
100	370	400	420

The values have been determined by means of an PI-F1 injector and a powder hose  $\varnothing$  11 mm, length 5 m.

These values have to be considered as reference values and depend on the characteristics of the powder and the status of the transport relevant pieces (e.g., injector).

PEM-X1

#### OPERATING MANUAL

## **6.5** CONNECTING THE SPRAY GUN

Unintentional putting into operation! Risk of injury.	
<b>Z</b> • <b>`</b> `	<ul> <li>Before any work on the device, in the event of work interruptions and malfunctions:</li> <li>→ Switch off the energy/compressed air supply.</li> <li>→ Relieve spray gun and device pressure.</li> <li>→ Secure the spray gun against actuation</li> </ul>
	<ul> <li>→ In the event of malfunctions, remedy the fault as described in the "Troubleshooting" chapter.</li> </ul>

#### Procedure:

- 1. Switch off the high-voltage generation on the control unit.
- 2. Before connecting the spray gun, check that all components (such as the nozzle system and union nut) are correctly fitted.
- 3. Connect electrical cable of spray gun to control unit.
- 4. Connect the powder feed hose to the spray gun and to the powder injector.
- 5. Connect the atomizing air hose to the spray gun and to the control unit.



OPERATING MANUAL



PEM-X1

## 6.6 GROUNDING

# 

#### No Grounding!

Risk of explosion and risk of electric shock.

→ Electrostatic control units and the associated spray equipment may only be connected to mains supplies with a protective conductor connection (PE conductor)!

Heavy powder mist if grounding is insufficient! Danger of poisoning. Insufficient paint application quality.
<ul> <li>→ Ground all device components.</li> <li>→ Ground the work pieces to be coated.</li> </ul>

For safety reasons, the control unit must be properly grounded. The ground connection to the energy supply (socket) takes the form of the mains connection cable's protective conductor, while that to the work piece / system is via the knurled screw on the rear of the control unit. Both connections are absolutely essential. If installed correctly as described above, the spray gun is grounded via the gun cable between the control unit and spray gun.

Good grounding of the work piece is also necessary for optimum powder coating.

## A poorly grounded work piece causes:

- dangerous electric charging of the work piece,
- very poor wrap-around,
- uneven coating,
- back spraying to the spray gun, i.e. contamination.

#### Prerequisites for perfect grounding and coating are:

- Clean work piece suspension.
- Grounding of spray booth, conveyor system and suspension on the building side in accordance with the operating manuals or the manufacturer's information.
- Grounding of all conductive parts within the working area.
- The grounding resistance of the work piece may not exceed 1 M $\Omega$  (megohm). (Resistance to ground measured at 500 V or 1,000 V).



#### **OPERATING MANUAL**

- The footwear worn by the operators must comply with the requirements of EN ISO 20344. The measured insulation resistance must not exceed 100 MΩ (megohms).
- The protective clothing, including gloves, must comply with the requirements of EN ISO 1149-5. The measured insulation resistance must not exceed 100 MΩ (megohms).

Sparks between conveyor, conveyor hooks (hangers) and work piece can occur if electric contact points between conveyor, conveyor hooks (hangers) and work piece are not sufficiently cleaned and therefore the work pieces are not sufficiently grounded!

These sparks can cause heavy radio frequency interference (EMC).

#### 6.6.1 GROUNDING THE POWDER COATING SYSTEM



- 1 Only use mains cables with grounding strand!
- 2 Connect grounding cable with booth and signal ground!
- 3 Connect grounding cable to an uncoated metal part of the booth!
- 4 All paint must be removed from hook and other hanger parts!
- 5 Wear electrostatically conductive gloves!
- 6 Wear electrostatically conductive footwear!
- 7 The floor must be electrostatically conductive!

VERSION 03/2014 ORDER NUMBER DOC 2326020

PEM-X1 WÂGNER

OPERATING MANUAL

# **7** OPERATION

## 7.1 TRAINING THE OPERATING STAFF

<b>Incorrect operation!</b> Bisk of injury and damage to the device	
<u> </u>	<ul> <li>→ The operating staff must be qualified to operate the entire system.</li> <li>→ Before work commences, the operating staff must receive appropriate system training.</li> <li>→ The operating staff must be familiar with the provisions of European standard DIN EN 50050-2.</li> </ul>

## 7.2 SAFETY INSTRUCTIONS

<b>Incorrect operation!</b> Risk of injury and damage to the device.
<ul> <li>→ If contact with powder products or cleaning agents causes skin irritation, appropriate precautionary measures must be taken, e.g., wearing protective clothing.</li> <li>→ The footwear worn by operating staff must comply with EN ISO 20344. The measured insulation resistance must not exceed 100 megohms.</li> <li>→ The protective clothing, including gloves, must comply with EN ISO 1149-5. The measured insulation resistance must not exceed 100 megohms.</li> </ul>



OPERATING MANUAL

#### 7.3 OPTIMIZING THE POWDER CLOUD FOR YOUR COATING

#### Procedure:

1. Switch on the high-voltage generation and the powder feed.

#### Note:

To minimize wear on the wearing parts, the total air volume should be below 5 Nm<sup>3</sup>/h!

The atomizing air should be adjusted for the:

- fan spray nozzle to 0.1 Nm<sup>3</sup>/h,
- round spray nozzle to > 0.2 Nm<sup>3</sup>/h
- 2. Adjust the powder quantity and the powder speed on a test piece.

## 7.3.1 RECOMMENDED SETTINGS FOR TOTAL AIR VOLUME

	Hose diameter			
Hose length	9 mm	10 mm	11 mm	12 mm
4 - 8 m		2.0 - 2.5 m³/h	3.0 - 3.5 m³/h	4.0 - 4.5 m³/h
8 - 12 m		2.5 - 3.0 m³/h	3.5 - 4.0 m³/h	4.5 - 5.0 m³/h
12 - 16 m		3.0 - 3.5 m³/h	4.0 - 4.5 m³/h	5.0 - 5.5 m³/h



#### OPERATING MANUAL

#### 7.4 SWITCHING OFF THE SPRAY GUN

By releasing the trigger the powder feed is stopped and the high-voltage switched off. To safely switch off the spray gun, e.g., for maintenance work, the control unit must be switched off.



#### 7.5 ADJUSTMENT OF POWDER QUANTITY

#### Note:

This function can only be activated in combination with the EPG-Sprint X control unit.

By pressing the buttons "+/-" the preset program values of the feed air (powder quantity) can be changed in the desired direction.

In this case the total air remains unchanged, the feed and dosing air is readjust accordingly.



LED display	Operation mode	
Flashing	Normal operation of gun	
Constant blinking	Activated program has been changed using the "+" "-" button.	
	By selecting another program the modified values of	
	the powder quantity are not taken over, however, the	
	current values of the other program are taken over	
	and the blinking changes to flashing.	
	By saving these settings the current values of the	
	powder feed are taken over in the current program.	
	The blinking changes back to flashing.	
	By activating the "Double Click" function the blinking	
	is switched off as well, the preset program values are	
	then active again.	
Permanent lighting	Trigger has been actuated with "Double Click", i.e., the	
	"Double Click" program is activated.	

VERSION 03/2014

ORDER NUMBER DOC 2326020



#### OPERATING MANUAL

#### 7.6 "DOUBLE CLICK" PROGRAM (HIGH DYNAMIC REMOTE)

This function is used to change quickly to another program during a coating operation. The operator can access a previously set program by double-clicking on the trigger lever on the spray gun, for example to recoat parts using different parameters (high-voltage, current limitation, air volumes etc.).

To access the function, press the trigger lever on the spray gun twice in quick succession and hold down. Upon releasing the trigger, the original program will be returned to.



VERSION 03/2014

ORDER NUMBER DOC 2326020



#### OPERATING MANUAL

## 7.7 REPRODUCIBLE SETTING OF THE NOZZLE POSITION



An adjustment tool is provided for the fan spray nozzle. It permits turning the fan spray nozzle without damaging the electrodes and without removing the union nut.

The union nut only has to be slackened.

PEM-X1

**OPERATING MANUAL** 

## **8** CLEANING AND MAINTENANCE

#### 8.1 CLEANING

#### 8.1.1 CLEANING STAFF

Cleaning work should be undertaken regularly and carefully by qualified and trained staff. The staff must be familiar with the DIN EN 50050-2 provisions. They should be informed of specific hazards during their training.

The following hazards may arise during cleaning work:

- Health hazard from inhaling powder lacquer
- Use of unsuitable cleaning tools and aids

#### 8.1.2 SAFETY INSTRUCTIONS



# DANGER

#### Explosive powder/air mixes!

Danger to life and damage to the device.

- → Before starting cleaning or other manual work, the high-voltage must be shut down and locked to prevent it from being switched back on!
- → The spray gun must be separated from the high-voltage supply and compressed air supply before any cleaning work is started!
- → Use only electrically conductive tanks for cleaning liquids! Ground the tank!
- → Preference should be given to non-flammable cleaning fluids.
- → Flammable cleaning liquids may only be used if, after switching off the high-voltage, all high-voltage conducting parts are discharged to a discharge energy of less than 0.24 mJ before they can be accessed.
  - Most flammable solvents have an ignition energy of around 0.24 mJ or 60 nC.
- → The cleaning agent's flash point must be at least 15 K above the ambient temperature.
- → Only mobile industrial vacuum cleaners of design 1 (see EN 60335-2) may be used to remove dust deposits.

PEM-X1

WÂGNER

#### OPERATING MANUAL

	<b>Incorrect maintenance!</b> Risk of injury and damage to the device.
•	<ul> <li>→ If contact with powder products or cleaning agents causes skin irritation, appropriate precautionary measures must be taken, e.g., wearing protective clothing.</li> <li>→ The footwear worn by operating staff must comply with EN ISO 20344. The measured insulation resistance must not exceed 100 megohms.</li> <li>→ The protective clothing, including gloves, must comply with EN ISO 1149-5. The measured insulation resistance must not exceed 100 megohms.</li> </ul>

## 8.1.3 CLEANING PROCEDURES

The cleaning intervals should be adapted by the operator depending on the level of use and if necessary the level of soiling.

If in doubt, we recommend contacting J. Wagner AG's specialist personnel.

The valid health and safety specifications and the safety instructions provided in Chapter 4 must be adhered to for all cleaning work.



OPERATING MANUAL

#### **8.2** MAINTENANCE

## 8.2.1 MAINTENANCE STAFF

Maintenance work should be undertaken regularly and carefully by qualified and trained staff. They should be informed of specific hazards during their training.

The following hazards may arise during maintenance work:

- Health hazard from inhaling powder lacquer
- Use of unsuitable tools and aids

Once the maintenance work is complete, the device must be checked by a qualified person to ensure a reliable condition.

## 8.2.2 SAFETY INSTRUCTIONS

$\mathbf{\Lambda}$	<b>Incorrect maintenance/repair!</b> Danger to life and damage to the device.
	→ Repair or replacement of devices or parts of devices are only allowed to be performed outside the hazard area by qualified personnel.
	→ Before starting maintenance or other manual work, the high- voltage must be shut down and locked to prevent it from being switched back on!
	→ The spray gun must be separated from the high-voltage supply and compressed air supply before any maintenance work is started!

•	🖄 DANGER
	<b>Incorrect maintenance/repair!</b> Risk of injury and damage to the device.
	<ul> <li>→ Have repairs and part replacements carried out only by specially trained staff or a WAGNER service center.</li> <li>→ Before all work on the device and in the event of work interruptions:         <ul> <li>Switch off the energy/compressed air supply.</li> <li>Relieve spray gun and device pressure.</li> <li>Secure the spray gun against actuation.</li> </ul> </li> <li>→ Observe the operating manual and service manuals at all times when carrying out work.</li> </ul>
PEM-X1

WAGNER

#### OPERATING MANUAL

<b>Incorrect maintenance!</b> Risk of injury and damage to the device.
<ul> <li>→ If contact with powder products or cleaning agents causes skin irritation, appropriate precautionary measures must be taken, e.g., wearing protective clothing.</li> <li>→ The footwear worn by operating staff must comply with EN ISO 20344. The measured insulation resistance must not exceed 100 megohms.</li> <li>→ The protective clothing, including gloves, must comply with EN ISO 1149-5. The measured insulation resistance must not exceed 100 megohms.</li> </ul>

## 8.2.3 MAINTENANCE PROCEDURES

The maintenance intervals should be adapted by the operator depending on the level of use and if necessary the level of soiling.

If in doubt, we recommend contacting J. Wagner AG's specialist personnel.

The valid health and safety specifications and safety instructions provided in Chapter 4 must be adhered to for all maintenance work.

Maintenance work	Point in time	
	per shift	weekly
Blow out gun and check for sintering	х	
Check gun settings	х	
Check gun discharge pressure	х	
Blow out powder hoses	x	
Check grounding		x
Check compressed air quality		Х
Check gun voltage		Х
Check powder hoses for bends and sintering		х



#### 8.2.4 REPLACING THE SPRAY GUN

Before replacing the spray gun, any powder residue must be thoroughly removed.

The wearing parts in the spray gun, marked in the spare parts list with " $\blacklozenge$ ", must be regularly checked and, if necessary replaced.



#### Procedure:

- 1. Switch off control unit.
- 2. Disconnect electrical cable 1 from control unit 2.
- 3. Disconnect powder feed hose 3 and atomizing air hose 4 from spray gun 5.
- 4. Connect powder feed hose 3 and atomizing air hose 4 to the new spray gun 5.
- 5. Connect electrical cable 1 to control unit 2.
- 6. Switch on the control unit.
- 7. The spray gun is ready for use again.

#### **8.3** REMOVING THE FAN SPRAY NOZZLE



#### Procedure:

1. Unscrew union nut from gun housing.

- 2.
- 2. Take union nut with nozzle system off gun body. The nozzle system remains inserted in the union nut.

#### Note:

If the nozzle system doesn't remain inserted in the union nut, the nozzle system and union nut must be replaced.



- 3. The parts can be separated by gently pressing the sliding ring on the fan spray nozzle.
- 4. Remove powder residues from the parts removed and from the spray gun.

#### Note:

Never place the spray gun or parts of the spray gun in cleaning agent.

As a rule the protective wedge needs to be checked for wear and replaced if necessary.

PEM-X1

#### **8.4** FITTING THE FAN SPRAY NOZZLE





- 1. Before inserting the electrode holder, the spring contact of the gun body and contact surface of the electrode holder should be checked. The spring contact must be clean and smooth-running, the gun body must also be clean and free of powder deposits.
- 2. Insert electrode holder into gun housing.



3. Attach fan spray nozzle to electrode holder and attach union nut.



4. Screw union nut onto gun housing until fan spray nozzle can no longer be turned by hand.



#### **8.5** REMOVING THE ROUND SPRAY NOZZLE



#### **Procedure:**

- 1. Pull off deflector cone.
- 2. Unscrew union nut from gun housing.
- 3. Take union nut with nozzle system off gun body. The nozzle system remains inserted in the union nut.

#### Note:

If the nozzle system doesn't remain inserted in the union nut, the nozzle system and union nut must be replaced.

- 4. Press nozzle system out of union nut by gently pressing on deflector cone sleeve.
- 5. Remove powder residues from the parts removed and from the spray gun.

#### Note:

Never place the spray gun or parts of the spray gun in cleaning agent.

As a rule the protective wedge needs to be checked for wear and replaced if necessary.

#### OPERATING MANUAL

#### **8.6** FITTING THE ROUND SPRAY NOZZLE



#### **Procedure:**

#### Note:

- Before inserting the electrode holder, the spring contact of the gun body and contact surface of the electrode holder should be checked.
   The spring contact must be clean and smoothrunning, the gun body must also be clean and free of powder deposits.
- 2. Attach deflector cone sleeve onto electrode holder.
- 3. Insert electrode holder into gun housing.
- 4. Slide union nut onto gun housing.
- 5. Screw union nut onto gun housing (hand-tight).
- 6. Slide deflector cone over deflector cone sleeve.

PEM-X1

#### OPERATING MANUAL

#### **8.7** REPLACING THE PROTECTIVE WEDGE

#### Note:

A wedge tool is available to prevent the protective wedge from being damaged when dismantling and inserting.

The wedge tool has a removal side (E) and an attachment side (A). Use the right side for the corresponding procedure!

You will find the necessary wearing parts and spare parts in Chapter 13 "Spare Parts" of this operating manual.



- 1 Wedge tool
- 2 Electrode holder (shown with a cut-away view to improve comprehension)
- 3 Protective wedge (when positioned)

#### Procedure:

- 1. Guide wedge tool 1 into electrode holder 2 up to stop.
- 2. Pull protective wedge 3 out of electrode holder 2 using wedge tool 1.
- 3. Press protective wedge 3 sideways out of wedge tool 1 manually (without tool).



#### OPERATING MANUAL

#### Note:

The same wedge tool is used to insert the protective wedge.



#### **Procedure:**

- 1. Guide protective wedge 2 into wedge tool 1.
- Insert both parts into opening on electrode holder up to stop.
   If it is not possible to push the wedge tool in as far as the X mark, rotate the wedge tool a

little until it can be pushed up to the mark. The mark X must be flush with the Y end of the electrode holder.

- 3. The protective wedge is now correctly assembled and the wedge tool can be pulled out of the electrode holder.
- The protective wedge remains inserted in the electrode holder.
   Prior to re-fitting, check whether the contact

points on electrode holder 3 and in gun housing 5 have been thoroughly cleaned so that the electrode tip is electrically connected to the high-voltage generator.

5. Mount fan or round spray nozzle with the corresponding electrode holder.

VERSION 03/2014

ORDER NUMBER DOC 2326020



OPERATING MANUAL

#### 8.8 CHANGING FROM FAN SPRAY NOZZLE TO ROUND SPRAY NOZZLE

The standard Corona spray gun is delivered with a fan spray nozzle. The nozzle can be changed easily, as described below.

The X1 R electrode holder is necessary to perform the change.



**Electrode tip!** Risk of injury.

→ Take care when fitting the X1 R electrode holder.



#### **Procedure:**

- 1. Unscrew union nut from gun housing.
- 2. Take union nut with nozzle system off gun body. The nozzle system remains inserted in the union nut.

#### Note:

If the nozzle system doesn't remain inserted in the union nut, the nozzle system and union nut must be replaced.

- 3. The parts can be separated by gently pressing the sliding ring on the fan spray nozzle.
- 4. Attach deflector cone sleeve onto X1 R electrode holder.



#### OPERATING MANUAL



#### **Procedure:**

- 5. Before inserting the electrode holder, the spring contact of the gun body and contact surface of the electrode holder should be checked. The spring contact must be clean and smooth-running, the gun body must also be clean and free of powder deposits.
- 6. Insert electrode holder into gun housing.
- 7. Slide union nut onto gun housing.
- 8. Screw union nut onto gun housing (hand-tight).
- 9. Slide deflector cone over deflector cone sleeve.

PEM-X1

#### OPERATING MANUAL

#### **8.9** ASSEMBLY OF THE CORONASTAR

The CoronaStar is a retrofit set for the spray gun, which helps to achieve a better surface quality (e.g., reduction of "orange peel").







#### Procedure:

- 1. Guide plug-in contact 1 of CoronaStar into drilled hole B on hook.
- 2. Attach clip 2 of CoronaStar to housing.

Flexible positioning in a range of  $\pm$  90° is possible.



#### 8.10 REPLACING THE SUSPENSION HOOK



#### Procedure:

- 1. Loosen retaining bolts on rear of hook and unscrew.
- 2. Slide hook in direction indicated by arrow and remove from gun housing.



3. Fit new hook on receiver and slide in direction indicated by arrow.



4. Fit retaining bolts and tighten.

PEM-X1

OPERATING MANUAL

# 9 INSPECTIONS IN ACCORDANCE WITH DIN EN 50050-2: 2014

If the system is used for electrostatic coating with flammable coating powders, testing should be undertaken in accordance with DIN EN 50050-2: 2014 as per Table 1.

PEM-X1 WÂGNER

#### OPERATING MANUAL

#### **9.1** OVERVIEW OF INSPECTIONS

Section	Type of inspection	Requirements	Inspection by	Type of inspection	Inspection interval
-	Resistance to ground of work piece's locating point	The resistance to ground of every work piece's locating point must not exceed 1 megohm (measurement voltage must be 1000 V). The design of the work piece receiver must ensure that the adapters remain grounded during coating.	C	ME/Cl Measure resistance to ground (work piece receiver - ground potential) max. 1 megohm @ 1,000 V.	weekly
2	Interlock between technical ventilation and high-voltage, compressed air and coating product supply	The technical ventilation should be interlocked such that the powder feed and high-voltage cannot be switched on, while the technical ventilation is not working effectively.	C	FI Test whether the system is safely stopped and the product supply, supply air and high-voltage are switched off when the ventilation is shut down.	annually
ĸ	Checking the electrostatic manual coating system for damage	Electrostatic manual coating systems may only be operated in an undamaged condition. Damaged devices must be decommissioned immediately and repaired immediately.	CP	FI Inspect and test (e.g., by measurement) whether all parts carrying high-voltage do not result in discharge which puts people at risk.	weekly
Legend: MA = Manufac EM = Employe CP = Capable I SE = Fire safe LC = Electricia P = Trained pe	:turer r serson ty engineer an erson	FI = Function inspe ME = Measuremen SI = Standard inspe VI = Visual inspecti CI = Continuous in TI = Technical inspe	ection it ection spection ection		

PEM-X1

OPERATING MANUAL

# **10** DISASSEMBLY AND DISPOSAL

#### **10.1** DISASSEMBLY



#### **Procedure:**

- 1. Switching off the system.
- 2. Lock the compressed air supply and decompress system.
- 3. Disconnect the gun connection cable from control unit.
- 4. Disconnect the powder feed hose to the spray gun and to the powder injector.
- 5. Disconnect the atomizing air hose to the spray gun and to the control unit.

#### 10.2 DISPOSAL



PEM-X1

OPERATING MANUAL

# **11** TROUBLESHOOTING AND RECTIFICATION

<b>Incorrect maintenance/repair!</b> Risk of injury and damage to the device.
<ul> <li>→ Have repairs and part replacements carried out only by specially trained staff or a WAGNER service center.</li> <li>→ Before all work on the device and in the event of work interruptions:         <ul> <li>Switch off the energy/compressed air supply.</li> <li>Relieve spray gun and device pressure.</li> <li>Secure the spray gun against actuation.</li> </ul> </li> <li>→ Observe the operating manual and service manuals at all times when carrying out work.</li> </ul>

# 

# Incorrect maintenance/repair!

Danger to life and damage to the device.

- → Wagner devices, protective systems and safety, monitoring and control equipment may only be maintained/repaired as defined in Directive 94/9/EC (ATEX) by trained Wagner service personnel or capable persons in accordance with TRBS 1203! Note national regulations!
- → Repair or replacement of devices or parts of devices may only be performed outside the hazard area!

#### VERSION 03/2014

ORDER NUMBER DOC 2326020

# PEM-X1

#### OPERATING MANUAL

Fault	Cause	Remedy
No electrostatic (e.g., no wrap around or no powder adhesion)	<ul> <li>Fault in the high-voltage generator</li> </ul>	Contact a Wagner service center
	• Electrical cable from spray gun to control unit faulty	Contact a Wagner service center
	Cascade in spray gun faulty	• Contact a Wagner service center
Poor powder wrap around Back-spray	Insufficient or no grounding	• See Chapter 6.6 "Grounding"
Powder outlet uneven or inadequate	Contamination	<ul> <li>Blow through parts carrying powder</li> </ul>
	Powder sintering	Clean parts carrying powder
	Feed device contaminated	<ul> <li>See operating manuals for the related devices connected</li> </ul>
	• Feed air / dosing air ratio incorrect	• Adjust at control module resp. control unit
	• Wear on powder injector nozzle	<ul> <li>Replace worn parts on powder injector <sup>1</sup>)</li> </ul>
Spray pattern is uneven	Parts of nozzle system worn	Replace worn parts
Cracks in the gun housing	Improper handling of the	Gun housing must be replaced
	powder spray gun	Contact a Wagner service center

1.) You will find the wear parts and spare parts in the powder injector operating manual.



OPERATING MANUAL

# **12** ACCESSORIES

#### **12.1** FAN SPRAY NOZZLE

	Order No.	Designation
P_01664	2321976	Fan spray nozzle, X1, complete

#### **12.2** DEFLECTOR CONE

	Order No.	Designation
P_01665	2321981	Deflector cone, D18, complete
P_01666	2321980	Deflector cone, D25, complete
P_01667	2321171	Deflector cone, D34, complete

#### **12.3** ELECTRODE HOLDER

	Order No.	Designation
P_01691	2322529	Electrode holder, X1 F ET
P_01692	2322490	Electrode holder, X1 R ET



#### **12.4** HOSE TAKE-UP

	Order No.	Designation
P_01693	2322761	Hose take-up, D10-D12, complete
DD P_01694	2322768	Hose take-up, D8-D10, complete

#### **12.5** CORONASTAR RETROFIT SET



Pos	Order No.	Designation
	2322868	CoronaStar, PEM-X1, complete
1	2322835	CoronaStar electrode, PEM-X1 ET

#### 12.6 WEDGE TOOL



Pos	Κ	Stk	Order No.	Designation
	*	1	2324124	Wedge tool, X1 + 20 wedges

 $\star$  available as accessory, not included in the purchased parts package



OPERATING MANUAL

#### **12.7** NOZZLE EXTENSION, X1 VL 150/300/500



Pos	Κ	Stk	Order No.	Designation
		1	2323366	Nozzle extension, X1 VL 150 (150 mm; 5.91 inches)
		1	2323356	Nozzle extension, X1 VL 300 (300 mm; 11.81 inches)
		1	2323338	Nozzle extension, X1 VL 500 (500 mm; 19.68 inches)
		1	2324147	Fan spray nozzle, X1 VL ET
	*	1	2324148	Round spray nozzle, X1 VL ET

★ available as accessory, not included in the purchased parts package

#### 12.8 NOZZLE EXTENSION, X1 VL 750



Pos	Κ	Stk	Order No.	Designation	
		1	2330497	Nozzle extension, X1 VL 750 (750 mm; 29.53 inches)	
		1	2324147	Fan spray nozzle, X1 VL ET	
	*	1	2324148	Round spray nozzle, X1 VL ET	

 $\star$  available as accessory, not included in the purchased parts package



OPERATING MANUAL

#### **12.9** POWDER HOSE

Order No.	Designation
351794 Powder hose $\emptyset$ 9 mm	
2310699	Powder hose $\varnothing$ 10 mm
2307502	Powder hose $\varnothing$ 11 mm
2310700	Powder hose $\varnothing$ 12 mm

#### **12.10** GUN CONNECTION CABLE

Order No.	Designation
2334275	Manual gun cable, PEM-X1 6m ET
2334568	Manual gun cable, PEM-X1 15m ET

#### Note:

The replacement of the gun cable may only be performed by Wagner service personnel!

#### 12.11 WALL MOUNT



Order No.	Designation	
2330223	Wall mount with bracket	

#### OPERATING MANUAL

#### **12.12** RECIPE STICKER

		4	Tribo Corona	[Nm <sup>3</sup> /b]	2	
		90	80	4.0	70	<b>() () ()</b>
		50	20	3.6	57	> 0.2
		70	40	3.6	50	
	$\longrightarrow$	82	20	3.6	45	🍋 🔶 👔
	name	80	100	4.5	80	💦 🔶 🕞
P5						N C
P6						(i)
P7						
P8						@
P9						$\bigcirc$
P10			İ			www.wagner-group.com/industry
WÂGN	IER					
						P 018

Order No.	Designation
2331223	Recipe sticker



OPERATING MANUAL

#### **12.13** POWDER MEASURING ADAPTER



for measuring powder quantities for the PEM-X1 spray gun



The powder measuring adapter is slid onto the nozzle.

OPERATING MANUAL

# **13** SPARE PARTS

#### **13.1** HOW CAN SPARE PARTS BE ORDERED?

To ensure proper spare parts delivery, the following information is necessary:

#### Order number, designation, and quantity

The quantity need not be the same as the number given in the quantity column "Stk" on the lists. This number merely indicates how many of the respective parts are used in each component.

The following information is also required to ensure smooth processing of your order:

- Billing address
- Delivery address
- Name of the person to be contacted in the event of any queries
- Type of delivery (normal mail, express delivery, air freight, courier etc.)

#### Identification in spare parts lists

Explanation of column "K" (labeling) in the following spare parts lists.

- Wearing parts
   Note: These parts are not covered by warranty terms
- = Not part of the standard equipment but available as a special accessory.

•	
	<b>Incorrect maintenance/repair!</b> Risk of injury and damage to the device.
	<ul> <li>→ Have repairs and part replacements carried out only by specially trained staff or a WAGNER service center.</li> <li>→ Before all work on the device and in the event of work interruptions:         <ul> <li>Switch off the energy/compressed air supply.</li> <li>Ensure that all system components are grounded.</li> <li>Secure the device against being switched back on without authorization.</li> <li>→ Observe the operating manual and service manuals at all times when carrying out work.</li> </ul> </li> </ul>



#### **13.2** PEM-X1 CORONA MANUAL GUN WITH A FAN SPRAY NOZZLE



#### PEM-X1 manual gun

Pos		K	Stk	Order No.	Designation
1			1	2322587	PEM-X1 Corona manual gun
2			1	2322761	Hose take-up, D10-12, complete
3	٠		2	9971364	O-ring
4			1	2320464	Union nut, X1
5	٠		1	2321976	Fan spray nozzle, X1, complete
6	٠	*	1	2322529	Electrode holder, X1 F ET
7	٠		1	2320488	Replacement protective wedge, X1
8			1	2320330	Gun hook, X1 ET
9			2	2316896	Screw
10			1	2324205	Wedge tool, X1
11			1	2313993	Hose, transparent $\varnothing$ 6 mm

- Wearing parts
- Not part of the standard equipment but available as a special accessory
- ★ Only available as a set



#### **13.3** PEM-X1 CORONA MANUAL GUN WITH A ROUND SPRAY NOZZLE



#### PEM-X1 manual gun

Pos	К	Stk	Order No.	Designation
1		1	2335844	PEM-X1 Corona manual gun
2		1	2322761	Hose take-up, D10-12, complete
3	•	2	9971364	O-ring
4		1	2320464	Union nut, X1
5	•	1	2322493	Electrode holder, X1 R, with nozzle
6	•	1	2320488	Replacement protective wedge, X1
7		1	2320330	Gun hook, X1 ET
8		2	2316896	Screw
9		1	2324205	Wedge tool, X1
10		1	2313993	Hose, transparent $\varnothing$ 6 mm

- Wearing parts
- Not part of the standard equipment but available as a special accessory
- ★ Only available as a set

## **13.4** ELECTRODE HOLDER, X1 R



#### Electrode holder, X1 R, with nozzles

Pos	К	Stk	Order No.	Designation
1	•	1	2322493	Electrode holder, X1 R, with nozzle
2	•	1	2322490	Electrode holder, X1 R ET
3	•	1	2320488	Replacement protective wedge, X1
4	•	1	2320503	Deflector cone sleeve, X1
5	•	1	2321981	Deflector cone, D18, complete
6	•	1	2321980	Deflector cone, D25, complete
7	•	1	2321171	Deflector cone, D34, complete

- Wearing parts
- Not part of the standard equipment but available as a special accessory
- ★ Only available as a set

#### **OPERATING MANUAL**

## **14** DECLARATION OF WARRANTY AND CONFORMITY

#### **14.1** IMPORTANT NOTES REGARDING PRODUCT LIABILITY

As a result of an EC regulation effective from January 1, 1990, the manufacturer shall only be liable for his product if all parts originate from him or are approved by him, and if the devices are properly mounted, operated and maintained.

The manufacturer will not be held liable or will only be held partially liable if third-party accessories or spare parts have been used.

With genuine WAGNER accessories and spare parts, you have the guarantee that all safety regulations are complied with.

#### **14.2** WARRANTY CLAIM

Full warranty is provided for this device:

We will at our discretion repair or replace free of charge all parts which within 24 months in single-shift, 12 months in 2-shift or 6 months in 3-shift operation from date of receipt by the purchaser are found to be wholly or substantially unusable due to causes prior to the sale, in particular faulty design, defective materials or poor workmanship.

The type of warranty provided is such that the device or individual components of the device are either replaced or repaired as we see fit. The resulting costs, in particular shipping charges, road tolls, labor and material costs will be borne by us except where these costs are increased due to the subsequent shipment of the device to a location other than the address of the purchaser.

We do not provide warranty for damage that has been caused or contributed to for the following reasons:

Unsuitable or improper use, faulty assembly or commissioning by the purchaser or a third party, normal wear, negligent handling, defective maintenance, unsuitable coating products, substitute products and the influence of chemical, electrochemical or electrical agents, except when the damage is attributable to us.

Components that have not been manufactured by WAGNER are subject to the original warranty of the manufacturer.

Replacement of a component does not extend the period of warranty of the device.

The device should be inspected immediately upon receipt. To avoid losing the warranty, we or the supplier company are to be informed in writing about obvious faults within 14 days upon receipt of the device.

We reserve the right to have the warranty compliance met by a contracting company.

The services provided by this warranty are dependent on evidence being provided in the form of an invoice or delivery note. If the examination discovers that no warranty claim exists, the costs of repairs are charged to the purchaser.

It is clearly stipulated that this warranty claim does not represent any constraint on statutory regulations or regulations agreed to contractually in our general terms and conditions.

J. Wagner AG

AGNER

**OPERATING MANUAL** 

#### **14.3** DECLARATION OF CONFORMITY

Herewith we declare that the supplied version of

- PEM-X1 manual gun, order no. 2322587, 2335844

complies with the following provisions applying to it:

- 94/9/EC (ATEX Directive)
- 2006/42/EC (Machine Directive)
- 2004/108/EC (EMV Directive)
- 2002/95/EC (RoHs Directive)
- 2002/96/EC (WEEE Directive)

Applied standards, in particular:

- prDIN EN 50050-2: 2011
- DIN EN 50050: 2007
- DIN EN 1127-1: 2011
- DIN EN 60079-0: 2010
- DIN EN 60079-31: 2010
- DIN EN 60079-7: 2007
- DIN EN 1953: 2010
- DIN EN 60204-1: 2007
- DIN EN ISO 80079-34: 2012
- DIN EN 14462: 2010
- DIN EN 60529: 2000
- DIN EN ISO 12100: 2011
- DIN EN 61000-6-2: 2011
- DIN EN 6100-6-4: 2011
- DIN EN 62061: 2010
- DIN EN ISO 13849-1: 2008
- DIN EN 50177: 2010

Applied national technical standards and specifications, in particular:

- BGI 764

Identification:

#### **CE Certificate of Conformity**

The CE certificate of conformity is enclosed with this product. If needed, further copies can be ordered through your WAGNER dealer by specifying the product name and serial number.

#### Order number:

PEM-X1 manual gun 2326024



#### **14.4** EC TYPE EXAMINATION CERTIFICATE

#### Physikalisch-Technische Bundesanstalt

Braunschweig und Berlin



## (1) EC-TYPE-EXAMINATION CERTIFICATE

(Translation)

- (2) Equipment and Protective Systems Intended for Use in Potentially Explosive Atmospheres - Directive 94/9/EC
- (3) EC-type-examination Certificate Number:

#### PTB 12 ATEX 5002

- (4) Equipment: PEM-X1 electrostatic hand-operated powder coating gun and PEM-X1 CG electrostatic hand-operated powder cup-gun with accessories.
   (5) Manufacturer: J. Wagner AG
- (6) Address: Industriestrasse 22, 9450 Altstätten, Switzerland
- (7) This equipment and any acceptable variation thereto are specified in the schedule to this certificate and the documents therein referred to.
- (8) The Physikalisch-Technische Bundesanstalt, notified body No. 0102 in accordance with Article 9 of the Council Directive 94/9/EC of 23 March 1994, certifies that this equipment has been found to comply with the Essential Health and Safety Requirements relating to the design and construction of equipment and protective systems intended for use in potentially explosive atmospheres, given in Annex II to the Directive.

The examination and test results are recorded in the confidential test report PTB Ex 12-51177.

- (9) Compliance with the Essential Health and Safety Requirements has been assured by compliance with: DIN EN 50050:2007, prEN 50050-2:2011, DIN EN 50177:2010
- (10) If the sign "X" is placed after the certificate number, it indicates that the equipment is subject to special conditions for safe use specified in the schedule to this certificate.
- (11) This EC-type-examination Certificate relates only to the design, examination and tests of the specified equipment in accordance to the Directive 94/9/EC. Further requirements of the Directive apply to the manufacturing process and supply of this equipment. These are not covered by this certificate.
- (12) The marking of the equipment shall include the following:

ZSEx10100e.dotm



EC-type-examination Certificates without signature and official stamp shall not be valid. The certificates may be circulated only without alteration. Extracts or alterations are subject to approval by the Physikalisch-Technische Bundesanstalt. In case of dispute, the German text shall prevail.

Physikalisch-Technische Bundesanstalt • Bundesallee 100 • 38116 Braunschweig • GERMANY

VERSION 03/2014

ORDER NUMBER DOC 2326020

PEM-X1

**OPERATING MANUAL** 

#### 14.5 FM APPROVAL

The PEM-X1 powder spray gun is approved in the USA and Canada using configuration drawing no. 2309729.



# CERTIFICATE OF COMPLIANCE

#### HAZARDOUS (CLASSIFIED) LOCATION ELECTRICAL EQUIPMENT

HAZARDOUS LOCATION ELECTRICAL EQUIPMENT PER CANADIAN REQUIREMENTS

The Sprint AF USA and Sprint 60L USA Manual Powder Spray Systems for use in Electrostatic Powder Finishing Applications using Class II Spray Materials when configured in accordance with drawing 2309729. The Sprint AF USA and Sprint 60L USA Trolleys are rated for use in Class II, Division 2, Groups E, F and G Hazardous (Classified) Locations. The PEM-X1, PEM-X1-CG, PEM-C4-HiCoat FM and PEM-C4-ERGO FM Manual Applicators, and PEA-C4-HiCoat FM and PEA-C4XL-HiCoat FM Automatic Applicators with either EPG-Sprint X, EPG-Sprint FM, EPG-S2 FM, EPG-Prima and EPG-2008 Control Units for use in Electrostatic Powder Finishing Applications using Class II Spray Materials when configured in accordance with drawing 2309729. Control Units are rated for use in Class II, Division 2 Hazardous (Classified) Locations. The EPG-Sprint X, EPG-Sprint FM Control Units have an indoor environmental rating of IP64. The PEM-C4-ERGO FM Manual Applicator, and PEA-C4-HiCoat FM and PEA-C4XL-HiCoat FM Automatic Applicators have an environmental rating of IP54.

Special conditions of use: The source electrical connection for the Control Units are to be connected in an unclassified (ordinary) location only.

Equipment Ratings:

The applicators are rated for use in Electrostatic Powder Finishing Applications using Class II Spray Materials when configured in accordance with drawing no. 2309729. The associated control units and mobile powder systems are rated for use in Class II, Division 2, Group E, F and G Hazardous Locations. The EPG-Sprint X EPG-Sprint FM Control Units have an environmental rating of IP64. The PEM-C4-ERGO FM Manual Applicator, PEA-C4-Hicoat FM, PEA-C4XL-HiCoat FM Automatic Applicators have an environmental rating of IP54.



FM Approvals 1151 Boston Providence Turnpike P.O. Box 9102 Norwood, MA 02062 USA T: **781 762 4300** F: 781-762-9375 www.fmapprovals.com

PEM-X1

#### OPERATING MANUAL



PEM-X1

#### OPERATING MANUAL



PEM-X1

## OPERATING MANUAL







Order No. 2326020 Edition 03/2014

#### Germany

J. WAGNER GmbH Otto-Lilienthal-Str. 18 Postfach 1120 **D-88677 Markdorf** Phone +49/ (0)7544 / 5050 Fax +49/ (0)7544 / 505200 E-mail service.standard@wagner-group.com

#### Switzerland

J. WAGNER AG Industriestrasse 22 Postfach 663 **CH- 9450 Altstätten** Phone +41/ (0)71 / 757 2211 Fax +41/ (0)71 / 757 2222

More contact addresses on the internet at: www.wagner-group.com Company/Locations/WAGNER worldwide

Subject to changes without notice

Document No. 11130849 Version B